

Short-Manual for i3-Benjamin Vertigarden

Detailed video documentation at: www.i3-garden.com





Tip: Bag must be completely flat and reach the corners

Contents:

1x Corpus (1), 1x lid (2), 1x base(3) *, 1x flat garden (4), 1x planting plate (5), 1x substrate-empty sack (6), i3-Dock set (s) (7) à 6 pcs with lids, 1x mounting kit (4 fixing pins, i3 sticker)

Optional: Available under www.i3-garden.com/shop

i3-automatic irrigation system, base with wheels (3) indoor/outdoor *

* = for some sets already included



- i3-Benjamin Pro-Kit - i3-Benjamin Pro-Kit indoor

step1 - Socket & Wheels

Insert the 4 wheels (8) with light pressure into the intended openings of the base

exception: i3-Benjamin Starter-Kit w/o base - stand or wall mounting with 2 brackets (total weight app.50kg)



Tip: 1x i3-Dock is already pre

step2 – complete the i3-Docks(7)

- Slide the cover plate on the base, pay attention to fit, press the front left + right tightly click / click
- Fix the octagonal ring firmly click



Tip: Bag must be completely flat in the body and in the corners

step3-corpus&substrate&planting plate

- Place the substrate sack (9) in the corpus, strip it out until it's flat in the body and in the corners
- <u>alternatively</u> insert the i3-empty sack and fill it with substrate -after step5



Tip: Press the fixing pins through the corpus material –see the marking (11)

- Place the planting plate (5) in the grooves below, left and right (the 2 small holes in the plate marking "top").
- Fix the plate with the 4 fixation pins (2x left + 2x right) -see markers (11) on the 2 middle bulges left + right



step4 – EPP-lid

• Put on the EPP-lid(2)



step5 - body & base

 Place the base(3) on a solid surface, put the body(1) in the socket (inclination to the rear)



Tip: outbreak = planting label (10) with pencil re-writable

step6 - i3-Dock(7) -mounting

- Cut the sack at desired positions with scissors or knives, remove breakouts ="planting signs"(10) for labeling
- Insert planted i3-docks(7) into the planting plate(5), turning to the right = locked



step7 – flat garden(4)

- Insert the Flat garden(4) into the lid opening Mit Substrat befüllen
- Fill with substrate

Accessories:

i3-automatic irrigation-system

here the flat garden is placed on the water reservoir with a plate

A steadily growing range of accessories, tips and tricks, FAQ's and much more can be found at: www.i3-garden.com/shop

Care Note: Use **lukewarm water** for cleaning with a **little dishwashing detergent** or a **cleaning sponge**. **Do not** use "sharp" cleaning agents.





"i3-Benjamin" VertiGarden – the story

birth date: 01.07.16, zodiac sign = 5

weight and dimensions: 5.520gr birth weight with 90/110 cm x 50cm x 30 cm

duration pregnancy: 3 years

parents: Arnold, Helene, Philipp, Karin, Andrea, Fritz

helping hands: Gerhard, Brigitte, Marco, Maria, Anton, Angelika and many more active companions during the pregnancy

godmother: Marisa name: "i3-Benjamin"

meaning "Benjamin": loves flowers – is grey - has a proboscis =i3-Dock - mobile on 4 elephant feet - it's fun_

Marisa in accordance with Benjamin Blümchen© *; "Child of Happiness"-Wikipedia; "Youngest son" -Bible

Why "i3": The "i" shows the way up=vertical, "i" also stands for intelligent/innovative;

"3" stands for the 3rd development-stage in gardening (1. flat bed, 2. hill bed/high bed, 3. vertical garden system),

"3" stands for the 3rd dimension = height

Notes on "My i3-Benjamin":		

Explanation: This product has been produced with the <u>greatest care in the EU</u>. All system materials used have the certificate "food save" according to EU-Directive 1935/2004/EC.



i3- Responsibility: We design and produce our products with the highest **sustainability requirements** – highest quality with maximum durability, low resource consumption, reusability = upcycling. Please use our closure bags further in your household. All materials used are **100% recyclable**.